

MVD AUTO COMPONENTS Pvt Ltd - OEM Reference Parts List (Updated 27th March 2015)

www.mvdindia.com

S. No.	Item	Ref OEM Part No.	MVD Part No.
1	Oil Pressure Switch	M/F : 3599307T91, 1877721M92, 1833647M1	5886
		Ford/Case/IH : 1534526C2, 3060472R91, K311686, K903851	
		Perkins : 3.152, 4.236, 6.354 Phaser 1000 Series 4 / 6 cylinders	
		Rover: GPS 101, 106, 108, 111, 117, 129, DRC 3202	
		BMC : 13H6462YR-2M201008	
2	Oil Pressure Switch	M/F : 1877721M91	5955
3	Oil Pressure Switch (Aftermarket design)	M/F : 1856097M91	5972
		Ford/Case/IH : D8NN9278BD, F1NN9278AA, D8NN9278AA, 81873524, 82028130, 83953056, 83953057, 83953096	
		Rover: 567920,586742,GPS104,110,115	
4	Oil Pressure Switch	Ford/Case/IH : 04998770, 05107603, 12326780, 4998770, 4998771, 5107603, 5160694, 5166458, 82036587	5885
5	Oil Pressure Switch (Adjustable Type)	M/F: 509682M91, 273541M1	5113-2B4NO
		Pekins: 2848A013 , MF135, MF150, MF165, MF175, MF180, MF230, MF235, MF245, MF255, MF265, MF275, MF285 (s/n 9A349239 & up), MF1080, MF1085, MF1100, MF1105, MF1130, MF1135, MF1150, MF1155, MF1505, MF1805	
6	Oil Pressure Switch	Perkins : 2848062	7090
7	Oil Pressure Switch	M/F : 3815773M92	6120
8	Oil Pressure switch	Ford/Case/IH: 3055238R93	7006
9	Oil Pressure Switch	Ford/Case/IH : 277016A1	7007
		McCormick Tractor	
10	Oil Pressure Switch	Ford/Case/IH : 87395493, 82030730, 82031395, 79043250, 5115055	5930
11	Oil Pressure Switch	Ford/Case/IH : 5161047	5938
12	Oil Pressure Switch	Ford/Case/IH : 87384756, 5163540	5945
13	Oil Pressure Switch	Ford/Case/IH : 87494631, 47134924	5939

14	Oil Pressure Switch (OEM type design)	Ford/Case/IH : 82036587	5924
15	Oil Pressure Switch (OEM type design)	Ford/Case/IH : 91450C1, 3055238R92, 3129031R91, 3132673R92, 376855R92, 100E9278, 81711892	5925
		Rover : OPS7210	
16	Oil Pressure Switch	Ford/Case/IH : 84053656	5929
17	Oil Pressure Switch (OEM type design)	Ford/Case/IH: 1534526C2	5926
18	Oil Pressure Switch	Ford/Case/IH : 441166, 84053657, 87675193	5928
19	Oil Pressure Switch	Ford/Case/IH : 87384755	5932
20	Oil Pressure Switch (OEM type design)	Ford/Case/IH : D8NN9278BD, F1NN9278AA, D8NN9278AA, 81873524, 82028130, 83953056, 83953057, 83953096	5923
21	Oil Pressure Switch	M/F : 1877721M92	5841
22	Oil Pressure Switch	Ursus: 50766460 / 50766461	5842
23	Oil Pressure Switch	Ursus : 50426370	5846
24	Oil Pressure Switch	Zetor: 50/42-637/0	5845B
25	Oil Pressure Switch	5040995310	5845
26	Oil Pressure Switch	80350921	5847
27	Oil Pressure Switch	83355942	5843
28	Oil Pressure Switch	976647	5850
29	Oil Pressure Switch	Ford/Case/IH : K311686, K903851, 3060472R91	5330
30	Oil Pressure Switch	Ford/Case/IH :81873524, D8NN9278BD, F1NN9278AA, E1ADDN9278, 81711891, 83953056	5935

31	Oil Pressure Switch	Rover: PRC6387, 4044	5315
32	Oil Pressure Switch	Landrover: 90519864	5314
33	Oil Pressure Switch (OEM type design)	John Deere : AR27977, AT85174	5876A
34	Oil Pressure Switch (Aftermarket design)	John Deere : AR27977, AT85174	5886D
35	Oil Pressure Switch (Double Terminal)	M/F : 35951861M2	TMP 432
36	Hyd Pump Warning Switch - MF260	M/F : 168704M1	5959
37	Hydraulic Pressure Switch	Ford /Case/IH : 87660483, 81867735, 135700710020	5942
38	Hydraulic Pump Switch	M/F : 1693367M1, 1693368M1, 3381286M1, 3381387M3	5957
39	Safety Start Switch	M/F : 1012043M91, 1679223M1, 1679223M2, 34198, 39121, 39855, 888501M2, 963417M2, 3381094M1, SMB497	5984
40	Diff Lock Switch	M/F : 3763601M1	5958
41	Safety Start Switch	M/F / UZEL : 0013886U92	5960
42	Safety Start Switch	M/F / UZEL : 0017373U91	5989
43	Safety Start Switch MF398	M/F : 3761983M91, 3598530M1, 3697346M1, 3697346M91, 1693818M1	5956
44	Safety Switch (Wire Terminal)	M/F : 181140M94 /M92/M93/M91	5371WT
45	Safety Switch (Stud Terminal)	Ford/Case/IH : 81817901, 81871479, C7NN7AR47A, C5NN7222C	5371ST
46	Safety Switch (Screw Terminal)	Ford/Case/IH : C7NN7A247B, C5NN7A247A, 237296	5371SC
47	Safety Start Isolator Switch	Ford/Case/IH : 81712538, E1ADDN11500	7010
48	Diff Lock Switch	Ford/Case/IH : 231262A1, 1332724C1	7011
49	Brake Switch	M/F : 3759508M91	5971
50	Brake Switch	Mercedes Trucks : 000 545 6909	7095

51	Reverse Gear Switch	5631100	5844
52	Reverse Gear Switch	Rover: PRC2911	5377
		OTOKAR : 71A00-36315-AA	
53	Reverse Gear Switch	Mercedes / Volkswagen : 0045452714	7060
54	Temp Transducer MF240/285/286	M/F : 1877731T92 / M93 / T92M, 1825118M91	5884
		Ford/Case/IH : K952332	
		David Brown : K952332	
55	Temp Transducer	540995240 / 38004736001	7159
56	Temp. Switch	Ford/Case/IH : 3057575R91	7008
57	Temp Switch	Ford/Case/IH : 3127956R91, 3073787R1	7169
58	Temp. Switch	Ford/Case/IH : A187687	7009
		John Deere : A187687	
		M/F : 3812023M1M	
59	Temp Sensor	Ford/Case/IH : 9712608, 87307746, D8NN10884A, 83917490, 83948391	5931
60	Temp Sensor	Ford/Case/IH : A166057, 84300765	5934
61	Temp. Sensor	Ford/Case/IH : 87307745	5931
62	Temp Sensor	Ford/Case/IH : C4AH10884A, 173321, 81784007, 81784077, 87554838	5275T
63	Temp Sensor	JCB	7092
64	Temp Sensor with Switch	Mercedes : 004 542 5617, 002 542 7317, 007 542 0917	7024
65	Oil Pressure Sensor / Transducer	Ursus : 380057250033	5937
66	Oil Pressure Sensor	Bizon : 504099518	5937B
67	Oil Pressure Sensor with Switch	Mercedes : 0025421717, 0075451717	7048
		MAN : 51.27421.0009	

68	Ignition Switch	M/F : 1446116M1, 1446116M91, 1865976M91, 1874120M91, 1874120M92, 1874120M93, 1874120T93, 1874120T94, 1874535M3, 2846130, 34228, 35670, 3640789M1	5867
		Perkins : 2846121, 2846130	
		David Brown : 3107556R92, K203992	
		Ford/Case/IH : 3107556R92, K203992	
		Valmet/Valtra : 32553200, 816450	
69	Ignition Switch	M/F 3000 Series : 00112243, 001123U91M- 3779699M	5999
70	Ignition Switch	Ford/Case/IH : E7NN11N501AA/AC/AB, D1NN11603B, D5NN11N572A, E8NN11N501AA, C5NN11N501A, C5NN11N572A, D5NN11A578A, D3NN11N501A, 81871583, 83959710, 83976890, 81838692, 83902803, 83999543, 87554837	5857
71	Ignition Switch	Ford/Case/IH : 282775A1	5822
72	Ignition Key (Single)	Ford/Case/IH : 1964831C2	5822-S
73	Push Start / Horn Switch	M/F : 189158M91, 393209R91	5820
74	Horn & Light Switch (Small)	M/F : 0013598U91, 2486119, 3763601	5997
		Ford/Case/IH : 5086008, 5132021	
		SAME : 2.7409.050.0	
75	Horn & Light Switch (Big)	M/F : 1668816M1 / M91, 1699034M91	5201
		Ford/Case/IH : 1502378C1, K300657, K300791	
		David Brown : K300657, 1502378C2	
76	Signal Switch	M/F : 001565M, 1881670M1, 3101795M1, 1672755, 1682977, 881670M1	5200
77	Fuel Pump Solenoid 12Volts (Lucas type with single stud terminal)	Perkins : 28480015	5973
78	Fuel Pump Solenoid 12Volts (Lucas type with 2 blade terminals)	M/F : 189646M1, 4224670M1, 28730179	5891
		Ford/Case/IH : 218323A1, 340521A1	
79	Fuel Pump Solenoid 12Volts (Lucas type with single stud terminal)	Lucas Type Fuel Pump 12 Volts	5068

80	Fuel Pump Solenoid 24Volts (Lucas type with single stud terminal)	Lucas Type Fuel Pump 24 Volts	5068X
81	Fuel Pump Solenoid 12 Volts (Delphi type with single stud terminal)	Ford/Case/IH : 83981012 E8NN9D278AA	5068E
		John Deere : RE22744/RE54064	
82	Fuel Pump Solenoid 12 Volts (Delphi type with 2 blade terminal)	Perkins : 26420472	7025
83	Fuel Pump Solenoid 12 Volts (Delphi type with single stud terminal)	Delhi / Lucas type Fuel Pump 12 Volts	7025A
84	Fuel Pump Solenoid 12 Volts (Bosch type with single stud terminal)	Ford/Case/IH : A77753	5069
		Fendt : F816201710020	
85	Fuel Pump Solenoid 12 Volts (Bosch type with single stud terminal)	2852741	5069E
86	Fuel Pump Solenoid 24 Volts (Bosch type with single stud terminal)	Bosch Type Fuel Pump 24 Volts	5069X
87	Glow Plug Thermostart (Blade Terminal)	M/F / Perkins : 1446935M1, 2666108, 3583453M2, 3583543M2, 893501M91	5527
		Ford/Case/IH : 603922, 81806046, 83933675, 87800843, C5NE9A436A, E1NN9A436AA	
		David Brown : K928523	
		John Deere : AR63103	
88	Glow Plug Thermostart (Screw Terminal)	M/F / Perkins : 2666103, 893501M1, 893501M91	5527ST
89	Glow Plug	Ursus : 50024641	5528
90	Resistor Block	Ford/Case/IH : 8NE10306	5818
91	Terminal Block	Ford / Case/ IH : 8NNN14448A	7166
92	Foot Operated Starter Switch	Ford / Case/ IH : 9N11450A / 356913R91	6142
		Delco : 1972119, 1972121, 1996487, 1996497	
93	Push Button Starter Switch	Ford : 8N11500	6143

94	Foot Operated Starter Switch	John Deere : 1882323 , 1925781	9191
95	Headlight Switch with Fuse	Ford / Case/ IH : 9N11652	6144
	Oil Pressure Sensors / Transducers	Complete Range (Equivalent to VDO / Continental Part Numbers)	
	Oil Pressure Switches		
	Temperature Sensors (Thermisters)		
	Temperature Switches (Bimetallic)		

Note : Manufacturers' names and OEM Part numbers mentioned above are for Reference Purpose only and are not intended to suggest that all our parts are used as Original Equipment for them. Since Vehicle manufacturers are constantly modifying their vehicles, we cannot guarantee the full accuracy of the information given in this list. It is only intended as a guide to our products.